



HOW TO READ THE BARCODE NUMBER

IBCA COMMODITY CODE




1 06 68333 00000 4




The IBCA COMMODITY CODE is the barcode in the upper left corner of the label. The item / part number may be the same as in the UCC code, but it may be different on some items.

Symbology is Interleaved Two of Five (12 of 5)

UCC / UPC SHIPPING CONTAINER CODE



9 06 83264 31272 5




The UCC / UPC SHIPPING CONTAINER CODE is the barcode in the lower right corner of the label.

Symbology is Interleaved Two of Five (12 of 5)

UPC



6 83264 31272 2



The Universal Product Code (UPC) is the "Retail" Barcode. Symbology is UPC-A